● Part Numbering

SAW Filters for RF/Local and IF · SAW Trap

(Part Number)　　SA | F | EB | 942M | FL0 | F | 00 | R15
　　　　　　　　　　❶　❷　❸　　❹　　❺　❻　❼　❽

❶Product ID

Product ID	
SA	SAW

❷Function

Code	Function
F	Single Filter
W	Dual Filter
E	Trap

❸Structure/Size

Code	Structure/Size
EB	Package Type

❹Nominal Center Frequency

Expressed by four-digit alphanumerics. The unit is hertz (Hz). If the unit is "MHz", it is expressed by three figures plus "**M**". If the unit is "GHz", a decimal point is expressed by capital letter "**G**".

❺Character Design

Code	Character Design
FL0	A serial number expresses the design version.

❻Board

Code	Board
F	Expresses the substrate being used.

❼Individual Specification

Code	Individual Specification
00	—

❽Packaging

Code	Packaging
R00	10,000 pcs./ø330mm Reel
R05	5,000 pcs./ø330mm Reel
R0A	15,000 pcs./ø330mm Reel
R0B	20,000 pcs./ø330mm Reel
R12	2,000 pcs./ø180mm Reel
R15	5,000 pcs./ø180mm Reel
R1X	10,000 pcs./ø180mm Reel