

■ Application

● General usage example

Handle an output signal of this sensor through an A/D converter.

1. Positive voltage (+) and negative voltage (-) are obtained in the clockwise and counter clockwise directions, respectively, with the static output as a reference.
2. It is possible to derive relative angle variation from integrating the output voltage.