



There is an air hole in the top right corner of the product.
 * This is not a pin 1 mark.

Pin Number	Symbol	Function
1	NC	-
2	NC	-
3	NC	-
4	APO X	The AMP2 output of the X-axis
5	AFB X	The return of AMP2 of the X-axis
6	AIN X	The input of AMP2 of the X-axis
7	OUT X	The output of the X-axis (Not AMP2)
8	Vref	Reference voltage
9	GND	Ground
10	OUT Y	The output of the Y-axis (Not AMP2)
11	AIN Y	The input of the AMP2 of the Y-axis
12	AFB Y	The return of AMP2 of the Y-axis
13	APO Y	The AMP2 output of the Y-axis
14	SCT	The control terminal of charge switch
15	Vcc	Power supply
16	NC	-

* NC: No Connect (Do not connect to any other circuit line.)

The central terminals are for internal use only.
 Do not connect and contact to any other circuit line and do not solder to any other pattern.

General Tolerance: ± 0.2
 (in mm)